

Install the tutorial of Barrowch M.2 full aluminum alloy digital display

Solid state drives heat

安装示例

INSTALL SAMPLE

BARROW



2. Apply thermal grease to one side of the hard disk drive



4. Apply thermal grease on the other side
(In the case of a hard disk drive with a chip on both sides,
select one side to apply the 0.5mm gray gasket)

Video installation tutorial has been uploaded to station b. players can jump to station B for viewing by identifying the two-dimensional code in the figure, or click "interactive center to beep beep beep" at the bottom of the public account page to jump to watch